

Jamar Plus + ?????????????? ????????????



Jamar Plus + ?????????????? ????????????

????????????: ??? ?????????????? ??????

Price
39,90 €

39,90 €

Not Available

★★★★★

[???? ??? ??????? ??? ?? ??????](#)

Manufacturer [Jamar](#)

???????????

?????????? ?? ?????????? ?? ?????? ??????? ?? ????? , ??? ?????? , ??? ??????? , ??? ??????? , ??? ?????????? ?????.


?? «Zero Button» ??????? ?? ??????????? ?? ??????????? ?? ??????????? ?? ??????????? ?? .

?? «Hold button» ?????? «????????» ???? ??????? ?? ???? ?????????????? ?? ???? ???????.

????? ?????????? ?? 20cm ??? 31cm

????????????????? ?????????? ??? ??????????

????? ???? ?????????????????? ?????? ?????? ??? ???? ?????????????? ??????????.



Instructions for Use

1. To turn on the digital goniometer, press the ON/OFF button.
 2. In order to change display direction 180 degrees, press the ON/OFF / DISPLAY button.
 3. To zero the display, press down on the ZERO/HOLD button for three seconds.
 4. Rotate the arms of the goniometer to take range of motion measurements.
 5. To lock the display of desired measurement, press the ZERO/HOLD button.
 6. When the measurement is in HOLD mode, the digital reader will not display a new measurement.
 7. To take off HOLD mode, press the ZERO/HOLD button.
 8. To turn off the digital unit, press down the ON/OFF button until the unit is turned off.

Buttons	Functions
ON/OFF	• Turn on and Turn off the digital unit
DISPLAY	• Rotates display 180 degrees
ZERO	• Locks the display of the measurement
HOLD	<ul style="list-style-type: none"> • Returns the display to zero • No memory function

Battery

1. One (1) 3V Lithium battery is included.
 2. Replacement of battery:
 - Press the battery release button on the side of the display unit.
 - The battery holder will open, like a drawer.
 - Pull the battery holder out and take the used battery out.
 - Insert a new battery with the “+” side down in the battery holder.
 - Gently insert the battery holder back in place and gently push it to see if it fits.
Note: Do not dispose the battery in fire. Dispose it complying with local regulations.

Reacut

- Precautions**

 - Do not drop the digital goniometer on a hard surface.
 - Do not submerge the digital unit in water or get wet to prevent damaging the electronic components.
 - Do not dispose the battery in fire. Dispose it complying with local law.
 - Do not store the digital goniometer with cleaning chemicals. The chemical vapors may affect the electronic components of the digital unit.



????????? ??? ?????????????:1